



NOTES:

1. SELF-ADHERING MEMBRANE SHEETS ARE USED FOR THRU-WALL FLASHING APPLICATIONS. SUPPLIERS' RECOMMENDATIONS FOR SURFACE PREPARATION TO BE FOLLOWED.
2. ALWAYS STOP MEMBRANE FLASHING BACK FROM EXTERIOR FACE OF VENEER. EXTEND THE DRIP EDGE USING PREPAINTED METAL TO SUIT.
3. DASHED LINE REPRESENTS OPTIONAL VAPOR BARRIER. CONSULT LOCAL BUILDING CODE FOR REQUIREMENTS OR CONTACT YOUR BASF TECHNICAL REPRESENTATIVE FOR DETAILS.

SHELF ANGLE DETAIL
BRICK VENEER/STEEL STUD WALL