



NOTES:

1. SELF-ADHERING MEMBRANE SHEETS ARE USED FOR THRU-WALL FLASHING APPLICATIONS. SUPPLIERS' RECOMMENDATIONS FOR SURFACE PREPARATION TO BE FOLLOWED.
2. INTEGRATE THE TRANSITION MEMBRANE AT FLOOR SLAB/STEEL STUD WALL JOINT WITH FOUNDATION WATERPROOFING OR DAMPROOFING SYSTEM.

FOUNDATION DETAIL
 BRICK VENEER/STEEL STUD WALL