



NOTES:

1. SELF-ADHERING SHEET MEMBRANES ARE USED FOR TRANSITION MEMBRANES AT ROOFLINE DETAILING POINTS INCLUDING BRIDGING THE GAP AT THE STEEL STUD WALL/ROOF DECK INTERSECTION INCLUDING UP AND OVER THE PARAPET. SUPPLIERS' RECOMMENDATIONS FOR SURFACE PREPARATION TO BE FOLLOWED.
2. TYPICAL APPLICATION SEQUENCE IS TO INSTALL THE TRANSITION MEMBRANES FIRST AT ROOF LINE BEFORE ROOFING CONTRACTOR INSTALLS ROOF. IDEALLY THE TRANSITION MEMBRANE IS INSTALLED BENEATH THE PARAPET WITH 6" EXTENDING OUT ONTO THE ROOF FOR CONNECTION TO ROOF AIR/VAPOR BARRIER BY ROOFER. OTHERWISE, THE TRANSITION MEMBRANE IS TO BE INSTALLED UP AND OVER PARAPET.
3. CHECK COMPATIBILITY OF TRANSITION MEMBRANES TO ADJACENT MATERIALS (TYPICAL FOR ALL DETAILS).

PARAPET DETAIL
BRICK VENEER/STEEL STUD WALL